


solo®

NOVA424 Tank, carrying strap, Pistol

Pos.-No.	Part No.	Quantity	Description
1	12877	1	Pedestal
2	14377	1	Pedestal screw-connection
3	12974	2	Bushing
4	12976	1	Filling strainer
5	14714	1	Tank lid
6	14715	1	Cylinder and pressure limiter
7	14380	1	Pressure limiter
8	10497	1	Valve ball (-)
9	12977	1	Plug pressure chamber
10	14332	1	Bellows
11	10497	1	Valve ball
12	10764	1	Suction tube
13	14381	1	Piston-pressure chamber
14	14382	1	O-ring
15	12978	1	Agitator
16	14330	1	Lifting rod
17	12975	1	Lever
18	14716	1	Lever
19	12979	1	Lance holder
20	14334	1	Carrying strap
21	13006	1	Strap holder



NOVA424 Spray Wand

Pos.-No..	Part No.	Quantity	Description
22	49 00 230P	1	Spray tube + 37 -38
23	48 00 170P	1	Shut-off valve incl. (-> 23 - 28
24	06 10 402K	1	Repair kit
25	40 74 335	1	Lever
26	40 74 295	1	Bolt
27	40 74 329 25	1	Support bracket
28	40 74 336	1	Screw cap <-)
29	14298	1	Hose
30	40 74 500	1	Clamp
31	00 31 356	1	Washer
32	40 74 337	1	Screw cap
33	00 62 271	1	O-ring
34	14300	1	Clamp
37	00 62 258	1	O-ring
38	40 74 337	1	Screw cap
40	49 0 0527	1	Adjust. Nozzle, red
41	40 74 148	1	Nozzle Cap
45	00 62 106	1	O-ring
46	00 62 115	2	O-ring
47	40 74 527 25	1	Elbow
48	40 74 922	1	Filter insert

