

solo[®]

453 Basic Unit

Pos.- No.	Part No.	Quantity	Description
2	PUMP	1	Pump
3	RELIEFVALVE	1	Safety valve
4	43 00 351	1	Lock nuts only
5	ORINGKIT	1	O Ring Repair Kit

453 Spray Wand

Pos.- No.	Part No.	Quantity	Description
1	48 00 170P	1	Trigger assy incl. (-> 1 - 4
2	06 10 402K	1	Repair kit
3	40 74 295	1	Bolt
4	40 74 329 25	1	Support bracket
5	00 62 271	1	O-ring
6	40 74 999	1	Screw cap <-)
7	49 00 230P	1	Spray tube incl. >8-10
9	00 62 258	1	O-ring
10	40 74 337	1	Screw cap
11	00 62 115	2	O-ring
12	40 74 527 25	1	Elbow
13	40 74 922	1	Filter insert
14	49 00 527	1	Adjust. Nozzle, red incl. (-> 14, 15
15	00 62 106	1	O-ring <-))
16	40 74 148	1	Nozzle Cap
17	44 00 318	1	Hose Only

